## **Ghost II Immobilizer Manual**

## **Entering your Disarm Sequence**

- 1. Turn your vehicles ignition on.
- 2. Enter your disarm sequence.
- 3. Wait for the vehicles indication to flash twice.
- 4. Put your foot on the brake and start the vehicle.

If this does not work then turn off the ignition, wait 10 seconds and start again at step 1.

The Ghost automatically returns to the armed state after 3 to 30 seconds with your vehicle ignition off, this timing is vehicle dependent.

## Service/Valet Mode

The Ghost has a service/Valet mode when it will not require the disarm sequence to be entered before starting or driving your vehicle.

The Service button is given to you by the installer.

- 1. Switch on the vehicle's ignition.
- 2. Enter your disarm sequence.
- 3. Wait for the 2 indication flashes.
- 4. Press the service button 5 times.
- 5. It will confirm service mode by flashing back the indication 5 times.

To exit service mode, you can switch ignition on and enter your disarm sequence and wait for 2 flashes.

## Changing disarm sequence.

- 1. Switch on the ignition.
- 2. Enter your current disarm sequence.
- 3. Wait for the indication to flash twice.
- 4. Press and hold the accelerator pedal all the way down.
- 5. Enter your current disarm sequence again.
- 6. The indications will now flash once every 3 seconds to confirm it's in learning mode. You can now release the accelerator pedal.
- 7. Enter your new 4 digit disarm sequence.
- 8. Every button will be confirmed by a flash right away.
- 9. After you enter your new sequence wait for 3 flashes of the indication.
- 10. Enter the same new disarm sequence again.
- 11. Wait for 2 flashes of the indication.

12. If it is successful, it will flash twice then switch the ignition off and test the new disarm code. If 4 flashes, it was unsuccessful turn off ignition and restart.

**Smart Vehicle Protection** – Guaranteed Security or your Money Back! The Autowatch Security Guarantee is applicable to the Ghost-II when installed on a vehicle. If in the unlikely event a vehicle that has a Ghost-II installed in it, is stolen, and not recovered within 2 months, we will refund the owner of the vehicle for the full amount they were charged to have the Ghost-II installed.

This guarantee is subject to the following terms and conditions listed below:

- 1) Car must belong to the person that paid to have the Ghost-II installed into the vehicle. This guarantee is not transferred to a new owner when the car is sold on. The guarantee is valid for as long as the original owner owns the vehicle, and the Ghost-II remains in the vehicle to which it was first registered.
- 2) The installation of the Ghost-II must be registered with us.
- 3) If a claim is made the following information must be provided before the money will be refunded:
  - a. Installation invoice must be provided.
  - b. Police reference number must be provided as proof that the theft has been reported.
  - c. If the customer has insurance theft cover, proof that the Insurance Company has paid out because the vehicle has not been recovered.
  - **d.** Proof of ID e. Proof of vehicle ownership. Payment will be done 2 months after the reported theft to ensure the vehicle has not been recovered.